

**PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES /
AIRCRAFT PARKING/DOCKING CHART**

ELEV AD 2224 M


7297 FT

TWR	118.55 ó 118.7	RMP	122.80
PDC	122.1	D-ATIS	127.650
SMC - N	121.85	FIS	126.875
SMC - S	121.0	EMERG	121.5
HELICOPTEROS MEX		118.15	

MEXICO

AEROPUERTO INTL/
INTL AIRPORT

BENITO JUAREZ



CAMBIO: FREQ

POSICIONES PLATAFORMA REMOTA ORIENTE		
PUNTOS	LATITUD	LONGITUD
P-48	19° 25' 52.6125" N	99° 04' 01.4885" W
P-48-A	19° 25' 53.2914" N	99° 04' 02.0456" W
P-49	19° 25' 53.6108" N	99° 04' 02.4447" W
P-50	19° 25' 54.6103" N	99° 04' 03.4016" W
P-50-A	19° 25' 55.0314" N	99° 04' 03.7428" W
P-51	19° 25' 56.9296" N	99° 04' 02.8259" W
P-EA	19° 26' 02.5767" N	99° 03' 55.4033" W
P-EB	19° 26' 01.8365" N	99° 03' 56.6338" W

HELIPUERTO		
HRP	LATITUD	LONGITUD
	19° 25' 56.4998" N	99° 03' 53.7184" W